

PERLICK SMART COUPLER



TAPPING A KEG

- Untap empty keg and turn beer flow control handle to OFF.
- Tap new keg, wait five seconds.
- Turn control handle to CLEAN position, wait five seconds, then turn to ON position.



TO RESTART THE SYSTEM

If beer does not flow, restart system by turning beer flow control handle to OFF. Wait five seconds, then turn to CLEAN for five seconds, and then to ON position.



TO CLEAN BEER LINES

- Turn beer flow control handle to OFF and attach cleaning adapter.
- Turn control handle to CLEAN and clean lines.
- Follow tapping instructions above.