

# DRAUGHT BALL TAPPING AND SERVING BEER



1



## KEEP DRAUGHT BALL COLD AT ALL TIMES

- Remove draught ball from carton
- Open plastic bag and fill partially with ice
- Place draught ball in plastic bag on top of ice
- Put draught ball back in carton
- Put more ice around draught ball

2



## CLEAN PUMP TAP BEFORE AND AFTER USE

- Invert tap tube under warm, running water
- Open tap faucet to let water run through tube
- Rinse other parts of tap as needed
- Do not submerge pump in water

3



## INSERT TAP INTO DRAUGHT BALL

Long Tube:

- Wet long tube with cold water
- Position tap's tube over one of the circular valves on cap of ball
- Strike top of tap sharply to pierce seal
- Push tube part way in

Short Tube:

- Position tap's short tube over other valve
- Strike tap sharply to break second valve seal
- Push tubes into draught ball until bottom of tap touches valve cap

4



## You're now ready to pour!

## DISPENSE BEER WITHOUT PUMPING

- Tilt cup/glass and push lever down to open faucet all the way
- Allow beer to flow down side of cup
- When cup is 2/3 full, straighten cup and continue to pour to create the perfect 1" head of foam

5



## IF BEER RATE SLOWS, PUMP TAP A FEW TIMES WITH FAUCET OPEN

- Pump three to six times
- Do not over-pump